

BIKE & ELLIPTICAL POWER CORDS & ADAPTORS

Key to using this guide:

Horizon Fitness manufactures a variety of ellipticals and stationary bikes. To find the replacement power cord or adaptor that is compatible with your product, simply search the columns below for your respective model name. Note the power cord number at the top of the column in which your model appears, and visit www.horizonfitnessoutlet.com to place your order or simply click on the text in the column header below.

AC Adapter - 7.5V: 061511-A2X	
Ellipticals:	Bikes:
3.0E	3.0B
4.0E	3.0R
CSE3	BSC3
E70	RSC3
Endurance 300	720B
Endurance Extreme	920B
Endurance Pro	
ESC3	
ESC4	
Kinetic Pro	
610E	
615E	
620E	
645E	
720E	
820E	
821E	
920E	

AC Adapter - 14.5V: 003486-A2	
Ellipticals:	Bikes:
2.2E	B30
3.1E	B31
E30	B52
E52	R30
E53	R52
E54	R6055
E6050	RB1
RE1	

AC Adaptor, 9V: 003503-A2	
Ellipticals:	Bikes:
4.1E	2.1B
	2.1R
	3.1B
	3.1R

AC Adaptor - 12V: 088261		
Ellipticals:	Bikes:	
2.3E	EX44	B600
3.2E	EX56	RC30
3.3E	EX65	RC40
4.2E	EX66	B701
4.3E	EX75	
CSE3.5	LS635E	
CSE3.6	PSE7	
CSE4.5	RE7.6	
CSE4.6	SXE7.7	
CX66	EX58	
E500	EX68	
E6	CE5.1	
E700	GS1050E	
E800	830E	
E95	CE6.0	
EX33	E701	
	E901	
	EX67	

AC Adaptor - 6V: 003494-A2X
EG5
EX22
625S

AC Adapter - 12V: 098773
E401
EX57
LS645E

AC Adapter - 12V: 1000094716
CE4.1

AC Adapter - 7.5V: 1000094714
725E

AC Adapter - 6V: 1000104762
LS625E
EX55

AC Adapter - 12V: 101339	
Ellipticals:	Bikes:
E5	R3

Power Cord-Socket: 002169-A
E900
E1200
EX76
EX77
AT1501
EX78
E1201