

BIKE & ELLIPTICAL POWER CORDS & ADAPTORS

Key to using this guide:

Horizon Fitness manufactures a variety of ellipticals and stationary bikes. To find the replacement power cord or adaptor that is compatible with your product, simply search the columns below for your respective model name. Note the power cord number at the top of the column in which your model appears, and visit www.horizonfitnessoutlet.com to place your order or simply click on the text in the column header below.

AC Adapter - 7.5V: 061511-A2X		AC Adapter - 14.5V: 003486-A2		AC Adaptor, 9V: 003503-A2		AC Adaptor - 12V: 088261		
Ellipticals:	Bikes:	Ellipticals:	Bikes:	Ellipticals:	Bikes:	Ellipticals:	Bikes:	Bikes:
3.0E	3.0B	2.2E	B30	4.1E	2.1B	2.3E	EX44	B600
4.0E	3.0R	3.1E	B31		2.1R	3.2E	EX56	RC30
CSE3	BSC3	E30	B52		3.1B	3.3E	EX65	RC40
E70	RSC3	E52	R30		3.1R	4.2E	EX66	B701
Endurance 300	720B	E53	R52	AC Adaptor - 6V: 003494-A2X		4.3E	EX75	
Endurance Extreme	920B	E54	R6055	EG5		CSE3.5	LS635E	
Endurance Pro		E6050	RB1	EX22		CSE3.6	PSE7	
ESC3		RE1		625S		CSE4.5	RE7.6	
ESC4		AC Adapter - 12V: 098773		AC Adapter - 12V: 1000094716		CSE4.6	SXE7.7	
Kinetic Pro		E401		CE4.1		CX66	EX58	
610E		EX57		EX69		E500	EX68	
615E		LS645E		AC Adapter - 12V: 1000094715		E6	CE5.1	
620E		AC Adapter - 7.5V: 1000094714		EX69		E700	GS1050E	
645E		725E		AC Adapter - 6V: 1000104762		E800	830E	
720E		AC Adapter - 6V: 1000104762		LS625E		E95	CE6.0	
820E		AC Adapter - 7.5V: 1000094714		EX55		EX33	E701	
821E		AC Adapter - 12V: 101339		AC Adapter - 12V: 101339			E901	
920E		Ellipticals:	Bikes:	AC Adapter - 12V: 101339			EX67	
Power Cord-Socket: 002169-A		E5	R3	AC Adapter - 12V: 101339				
E900				AC Adapter - 12V: 101339				
E1200				AC Adapter - 12V: 101339				
EX76				AC Adapter - 12V: 101339				
EX77				AC Adapter - 12V: 101339				
AT1501				AC Adapter - 12V: 101339				
EX78				AC Adapter - 12V: 101339				
E1201				AC Adapter - 12V: 101339				