

Motor Control Board Replacement Reference List

013674-DG	032671-HF	032669-IF	013701-AA	098847 (no elevation)	067266-AA
1.1T	1.0AT	3.2T	5.2T	Evolve	T74
2.0 T	1.2T	3.3T	5.3T	Evolve SG	
2.1 T	1.3T	4.2T	PST Pro	Evolve SS	
3.0 T	2.2T	CST4	PST8		
3.1 T	2.3T	CST4.5	T1200		
4.0 T	CST3	CST4.6	T6		
4.1 T	CST3.5	CST5	T84		
5.0 T	CST3.5X	CT7.0			
5.1 T	CST3.6	CT83			
Advance 200	CT5.0	GS1035T			
Advance 205	CT61	GS1040T			
Advance 300	CT81	PST6			
Advance 400	DT650	RCT7.6			
Advance 500	DT680	T1201 (All colors)			
Alpine	DT850	T4			
Omega	LS760T	T53			
Omega II	LS780T	T54			
Paragon	LS925T	T63			
Paragon II	RST5.6	T64			
Quantum	T10K	T700			
Quantum II	T401	T73			
RT1	T50	T800			
T20	T500	T82			
T25	T51	T83			
T30	T52	T900			
T35	T605	T901 (All colors)			
T40	T61	T92			
TSC 2	T62	T93			
TSC 3	T70	WT950			
TSC 4	T701	WT951			
TSC 5	T71				
	T72				
	T805				
	T81				
	T90				
	T91				
	T95				
	WT751				

Key to using this guide:

Horizon Fitness manufactures a variety of treadmills. To find the replacement motor control board that is compatible with your product, simply search the columns for your respective model name. Note the motor control board number at the top of the column in which your model appears, and visit www.horizonfitness.com to place your order or simply click on the column header.