

Key to using this guide:

Horizon Fitness manufactures a variety of treadmills. To find the safety key that is compatible with your product, simply search the columns below for your respective model name. Note the safety key number at the top of the column in which your model appears, and visit www.horizonfitnessoutlet.com to place your order or simply click on the text in the column header below.

SAFETY KEYS	016488-Z	013871-A	009715-B	016167-Z	082397	051345-A	1000105094
	1.1T	2.1T	RT1	CST3	2.3T	30750	T103
	1.2T	2.2T		CST3.5	3.3T	415T	T102
	1.3T	3.0T		CST3.5X	5.3T	610T	T101
	2.0T	3.1T		CST4	CST3.6	620T	GS950T
	Advance 200	3.2T		CST4.5	CST4.6	621T	CT9.1
	Advance 205	4.0T		CST5	CT5.0	700T	CT7.1
	Advance 300	4.1T		CT61	CT7.0	710T	CT5.1
	Advance 400	4.2T		DT650	CT81	715T	
	Advance 500	5.0T		DT680	CT83	720T	
	Alpine	5.1T		DT850	GS1035T	725T	013877-A
	Omega	5.2T		SMT61P	GS1050T	730T	Evolve SG
	Omega II	PST6		T10K	LS760T	810T	Evolve HSN
	Paragon	PST8		T51	LS925T	811T	Evolve Simple Steps
	Paragon II	PSTPro		T52	RCT7.6	820T	
	Quantum	T401		T53	RST5.6	821T	
	Quantum II	T50		T54	T1200	830T	087474
	T20	T70		T605	T4	910T	GS1040T
	T25	T95		T61	T500	920T	T1201
	T30			T62	T6	930T	T901
	T35			T63	T700	T90	
	T40			T64	T73	611T	
	TSC2			T71	T74	611T	
	TSC3			T72	T800	735T	
	TSC4			T805	T81		
	TSC5			WT751	T82		
				WT950	T83		
				WT951	T84		
					T900		
					LS780T		
					T91		
					T92		
					T93		