

Removing the Exercise Bike Side Case

Tools: Phillips screwdriver, 14mm socket, 15mm wrench, crank puller.

Note: Diagram on following page.

1. Remove the pedal (T07) with a 15mm wrench.
2. Remove the black cap (Q11) from the center of the crank disk.
3. Remove the crank arm nut (T09) with a 14mm socket.
4. Using a crank puller, thread the puller onto the crank arm (AT1). Extract the crank arm and crank disk from the axle and remove.
5. Remove the accent piece by gently lifting up at the bottom of the accent piece and tilting towards the front of the machine.
6. Remove the screws that attach the side cover (Q02) in place.
7. Attach new side cover.
8. Attach the accent piece, placing the bottom tab into position first then placing the top tab into position.
9. Attach the crank disk and crank arm to the crank axle. Place black cap onto the center of the crank disk.
10. Replace pedal arm cap.
11. Attach the pedal.
12. Test ride the exercise bike to make sure it is working correctly.

